

# Connecting your Serv Pro to your Link. Wireless and wired with ethernet

Single wired connection with ethernet



1, Navigate to network setup



2, Click Wired



3, Make sure ethernet is connected in these ports on Serv pro & Link



4, Check status to make sure connected properly.



5, For succesful connection status should look similar to this and not be blank

Single or Multiple Wireless connection




1, Navigate to network setup




2, Click WiFi



3, Click Access Point



4, Click Infrastructure



5, Click scan for network




6, Connect to Links WiFi. For multiple Serv Pros, follow these steps again

Connecting to Link with Phone




1, Turn on link and make sure these LED are lit up. Can take a few minutes




2, Connect Phone WiFi to Link





3, Default Password is Link(followed by numbers below Link)



4, Open VUER on Phone



5, Hit Camera, Followed by refresh



6, Add Serv Pro(s) to feed, then hit Done